

BETO Standing

Instructions for the lighting configuration of a BETO Standing

- 1 Use the provided photometric file
Attention: you only get the light emitting surface (cyan lines in drawing)
- 2 Create two boxes*, one with 75mm and the second with 285mm
*blue lines in drawing
- 3 Set the two boxes and the photometric file as shown in the following drawing

