

NOBA 60 adjustable

MOVE IT 10

030-6820437



Project / Type _____

Notes _____

Count / Date _____



General

Ceiling / Wall , Track _____

tilt max 90° _____

rotation 365° _____

traffic white , RAL9016 ¹ _____

IP20 _____

851 lm _____

LED

2700 K _____

CRI ≥ 90 _____

L80 / 50000 h _____

initial MacAdam ≤ 2 SDCM _____

R_g: 99 , R_f: 91 , R₍₁₋₁₅₎: 89 _____

MR 0.53 _____

MDER 0.48 _____

Optical

Wide Flood _____

beam angle 67° _____

Electrical

DALI-2 _____

8.1 W _____

PC3 _____

105 lm/W _____

1 DALI Addr. _____


Physical

diameter 60 mm _____

height 60 mm _____

¹ RAL code


Light distribution



wide flood 67°

h (m)	EO° (lx)	ø (m)
1	809	1.31
2	202	2.63
3	90	3.94
4	51	5.26
5	32	6.57

Product drawing



Installation instructions



NOBA 60 adjustable

MOVE IT 10

030-6820437



Project / Type

Notes

Count / Date

Maintenance Factors

Operating Time [h]	10 000	20 000	30 000	40 000	50 000
LLMF	0.96	0.92	0.88	0.85	0.81
LSF	1	1	1	1	1

MF	LMF × RSMF × LLMF × LSF	RSMF ^a	Room Surface Maintenance Factor
MF	Maintenance Factor	LLMF	Lamp Lumens Maintenance Factor
LMF ^a	Luminaire Maintenance Factor	LSF	Lamp Survival Faktor

^a According to "CIE 97, Maintenance of indoor electric lighting systems", 2005, ISBN 3-900-734-34-8. The values must be determined by the planner.

