

NOBA 40 adjustable

MOVE IT 10

030-6800538



Project / Type _____

Notes _____

Count / Date _____



General

Ceiling / Wall , Track _____

tilt max 90° _____

rotation 365° _____

jet black , RAL9005 ¹ _____

IP20 _____

428 lm _____

LED

3000 K _____

CRI ≥ 90 _____

L80 / 50000 h _____

initial MacAdam ≤ 2 SDCM _____

R_g: 100 , R_f: 91 , R_{f1-15}: 88 _____

MR 0.59 _____

MDER 0.53 _____

Optical

Wide Flood _____

beam angle 67° _____

Electrical

DALI-2 _____

3.5 W _____

PC3 _____

122 lm/W _____

1 DALI Addr. _____


Physical

diameter 40 mm _____

height 40 mm _____

¹ RAL code


Light distribution



wide flood 67°

h (m)	EO° (lx)	ø (m)
1	407	1.31
2	102	2.63
3	45	3.94
4	25	5.26
5	16	6.57

Product drawing



Installation instructions



NOBA 40 adjustable

MOVE IT 10

030-6800538



Project / Type

Notes

Count / Date

Maintenance Factors

Operating Time [h]	10 000	20 000	30 000	40 000	50 000
LLMF	0.96	0.92	0.88	0.85	0.81
LSF	1	1	1	1	1

MF

MF

LMF^a

$LMF \times RSMF \times LLMF \times LSF$

Maintenance Factor

Luminaire Maintenance Factor

RSMF^a

LLMF

LSF

Room Surface Maintenance Factor

Lamp Lumens Maintenance Factor

Lamp Survival Faktor

^a According to "CIE 97, Maintenance of indoor electric lighting systems", 2005, ISBN 3-900-734-34-8. The values must be determined by the planner.

